
Document No:ZQK-332(134)-1


Installation Manual for the Anti-Vibration PTFE Joint

## ZRJ-BT


ZENSHN



- Please confirm whether there is any dama of sealing surface.
  Please confirm whether there is any dama
- Please confirm whether there is any damage of inside and outside.



- Before installation, please wipe off the dust of the piping side flange and a rubber body seal side with a rag etc., check that there are no foreign substances, and set the product between the piping flanges.
- ② Please insert the set bolt toward the piping side from the product side. Moreover, in order to prevent the loosening of the nut, please use a spring washer.



Please refer to the value of Table 3 for the tightening torque that becomes the standard of tightening.





Table3 Tightening torque	
Diameter	Tightening torque
25A~40A	30N•m
50A~100A	30N•m
125A~200A	40N∙m

Please confirm whether the flange face is parallel before tightening.



## 

- 1) This product is not designed for absorb the axial movement but vibrations.
- The piping system might resonate when the fixation of piping is insufficient. Please do the fixation near ZRJ-BT.
- 3) Please carry out the welding work of the piping before the attachment of our product. If you have to carry out the welding work after attaching the piping, please earth the welding properly, also put a protective cover around our product so that the welding current does not flow into the piping system.
- On the discharge side must be attached in this order reducer, a product, non return valve, and stop valve.

